



CUVE PLOUF

DUNK TANK



INSTALLATION DE LA MACHINE

1. Trouver une surface nivelée où installer et tranquillement lever la cuve en place.
2. Détacher et déplier la toile de cible.
3. Ne pas déposer les plateaux sur un rond de poêle allumé ou une flamme vive.
4. Vérifier que le bouchon de vidage est bien en place et remplir d'environ 1 900 litres d'eau.
5. Placer la partie aplatie du bras de cible dans le mécanisme sous le siège et placer l'autre partie au travers de la toile de cible et y attacher la cible.
6. Vérifier que le siège est bien barré et que le bras de cible déclenche bien son opération.

MACHINE INSTALLATION

1. Select a level area for set-up and slowly lift the tank upright.
2. Unsecure the target wing and swing it into position.
3. Do not put unit on a hot stove or an open flame.
4. Check the drain plug into place and fill with approximately 500 gallons of water
5. Place the flattened end of the target arm into the trigger mechanism, under the seat and put the other end through the target backdrop and attach the target.
6. Check to see if the seat is properly lock in and the lever releases it when the target is hit.

RENONCIATION DE RESPONSABILITÉ

- Une supervision par un adulte en tout temps.
- Toujours garder la cuve remplie à environ 8" de rebord lors de son utilisation.
- Toujours garder la cuve vide si non utilisée.
- Une seule personne dans la cuve et ne jamais se tenir debout sur le siège ou sur les rebords.
- Les plongeurs devraient être d'au moins 5' de haut.
- Ne pas utiliser la cuve sous l'influence de substances telles que drogues et alcool.
- Ne pas utiliser la cuve s'il y a danger d'orages, d'éclairs ou de vents violents.

Bravo n'est aucunement responsable de blessures, mineure ou grave, suite à l'utilisation de la cuve dû à une utilisation abusive ou inadéquate de l'appareil.

Je reconnais avoir lu et compris les instructions et mises en garde sur la cuve plouf.

WAIVER OF LIABILITY

- Adult supervision required at all times
- Keep water level filled at least 8" from top of tank while being used.
- Drain dunk tank when unattended.
- Only one person at the time allowed in the tank and never stand up on the seat.
- Keep all users over 5' tall.
- Do not use alcohol or drugs while operating.
- Do not operate during bad weather, lightning or strong winds.

Bravo will not be responsible of injuries, minor and serious, if these rules are not followed or if the tank gets misused.

I have read and understand the instructions and the safety rules of the dunk tank.

Nom : _____

Date : _____ / _____ / _____

Signature : _____

Contrat No : _____

Bravo Location Rentals Inc.

Montréal | 514.685.8000 | 800.685.0064 | 2055 boul. Hymus, Dorval QC, H9P 1J8
 Ottawa | 613.807.5505 | 800.685.0064 | PO Box 90043 CP Place, Ottawa ON, K1V 1J8
 bravoparty.com |    

2016-12-27

B:\Instructions\Cuve Plouf.docx

© 2016 Bravo Location Rentals. Tous droits réservés. All rights reserved.